



SPECIFICATIONS

Product Description: COOLER Part Number: 9991 VORTEX

GENERAL DESCRIPTION:

Vortex Tubes are an effective, low cost solution to respiratory cooling needs. With no moving parts, a vortex tube spins compressed air to separate the air into cold and hot air streams by forcing the compressed air through a generation chamber which spins the air centrifugally along the inner walls at a high rate of speed toward the control valve. A fraction of the hot air is discharged at the control valve. The remainder of the slower air stream is forced to counter-flow up through the center of the high-speed air stream, giving up heat, through the center of the generation chamber finally exiting through the opposite end as extremely cold air.



Body: Aluminum

Fitting: Hansen 1/4" (.63cm) plug (series 1000) Stainless Steel

Belt: Nylon

BENEFITS:

- Uses filtered compressed air
- Provides continuous cool air delivery
- Easy temperature adjustment even with gloved hands
- No moving parts
- Exceptionally reliable
- A control valve allows for temperature adjustment
- Will cool compressed air by 25° F
- Requires an air supply pressure range from 50-115 psi



1360 Shiloh Church Road Piedmont, SC 29673 864-846-8740 800-622-3530 FAX: 800-362-7231 <u>www.allegrosafety.com</u>