



# **SPECIFICATIONS**

Product Description: AMBIENT AIR PUMP A750

Part Number: 9821

Style: ROTARY VANE

## **GENERAL DESCRIPTION:**

Portable & lightweight air source for one hood user, or up to two full or half face respirator users. Solid performance in applications such as painting, cleaning, sanding or chemical handling operations.

# **CONSTRUCTION:**

- · Rigid metal base and housing
- Brass and galvanized steel plumbing
- Quick-connect Rectus (OBAC) fitting
- Adjustable brass pressure relief valve
- Steel handle
- Powder coated blue



#### PUMP:

\*Warning: Ambient Air Pumps are not to be used with generators

\*\*Warning: Air inlet to the pump must be located where breathable air can be assured at all times

Type: Oil-less, rotary vane

Vanes: Carbon construction (4ea/ replaceable) (2" (5.0cm) X 1.5" (3.8cm) X 0.219" (.55cm))

Inlet Filter: 50 Micron felt material with metal grid inlet filter housing.

Exhaust Filter: 0.3 Micron HEPA

Pressure Gage: 1½" (3.8cm) face, steel housing (0-15 psi (0-1.03 bar))
Pressure: 2-12 psi (.14-.83 bar) working (15 psi (1.03 bar) max)

Performance: 0-10 CFM (0-16.99 m<sup>3</sup>/hr) @ 60 Hz (adjusted via pressure relief valve)

0-8 CFM (0-13.59 m<sup>3</sup>/hr) @ 50 Hz (adjusted via pressure relief valve)

Airline length: 100 feet (30.4m) maximum from pump to respirator (sold separately).

Noise level: At pump: 90 dB

At 6 feet (1.82m): 74 dB At 10 feet (3.04m): 72 dB

MOTOR:

HP: 3/4 HP

Certifications: UL Recognized, CSA Certified Volts: 15V/230V AC, Single Phase

RPM: 1725 RPM @ 60Hz/1425 RPM @ 50 Hz Current Draw: 115V 12A @ 60 Hz/12.2 -14A @ 50 Hz Current Draw: 230V 5.9A @ 60 Hz/7.1-7.4A @ 50 Hz

Cord: 10' (3.04m) AWG 16/3 SJ00W 300V with integrated ON/OFF switch

Plug: Integrated NEMA 5-15

## **DIMENSIONS:**

Length In (cm)	Width In (cm)	Height In (cm)	Weight Lbs (Kg)
16" (40.6 cm)	9" (22.8 cm)	13" (33 cm)	53 lbs (24 kg)

1360 Shiloh Church Road Piedmont, SC 29673 864-846-8740 800-622-3530 FAX: 800-362-7231 <u>www.allegrosafety.com</u>