



SPECIFICATIONS

Product Description: **FIT TEST KIT**
Part Number: **2040**
Style: **SACCHARIN**

GENERAL DESCRIPTION:

This kit offers qualitative OSHA compliant fit testing for disposable and reusable dust and mist respirators. Saccharin has a sweet taste to indicate failure on the respirator fit test. New disposable glass ampoules make pouring solution into nebulizers easier and reduce the chance of contamination.

KIT:

- Test hood
- Sensitivity nebulizer
- Test nebulizer
- Box of Sensitivity Solution, 6 ampules
- Box of Test Solution, 6 ampules

HOOD:

- Poly-coated
- Clear viewing window
- Surged seams
- Reusable

SACCHARIN:

- Glass ampoules
- With pre-drilled plastic cap for easy pouring
- Plastic protection from broken glass
- One time use
- Averages 3-5 fit tests per tube
- Contains 2.5cc of solution

NEBULIZER:

- Natural Latex rubber air bulb for easy operation
- Converts 5 cc (ml) of liquid into aerosol 0.3 to 5.0 microns particle size
- Complete with extra jet and replaceable plastic caps
- Break-resistant polycarbonate plastic (Lexan®) that easily disassembles for washing
- Dimensions: 2" (5.0 cm) X 2" (5.0 cm) X 7" (17.7cm)

AVAILABLE:

2040-11K Additional Saccharin Sensitivity solution ampoules (6/box)

2040-12K Additional Saccharin Test solution ampoules (6/box)

2040-08N Additional Nebulizers (each)

