



SPECIFICATIONS

Product Description: **FIT TEST KIT**
Part Number: **2041**
Style: **BITREX**

GENERAL DESCRIPTION:

This kit offers qualitative OSHA compliant fit testing for disposable and reusable dust and mist respirators. Bitrex creates an unmistakable bitter taste that indicates breakthrough on the respirator fit. New disposable glass ampoules make pouring solution into nebulizers easier and reduce the chance of contamination.

KIT:

- Test hood
- Sensitivity nebulizer
- Test nebulizer
- Box of Sensitivity Solution, 6 ampoules
- Box of Test Solution, 6 ampoules

HOOD:

- Poly-coated
- Clear viewing window
- Surged seams
- Reusable

BITREX:

- Glass ampule
- With pre-drilled plastic cap for easy pouring
- Plastic protection from broken glass
- One time use
- Averages 3-5 fit tests per tube
- Contains 2.5 cc of solution

NEBULIZER:

- Natural Latex rubber air bulb for easy operation
- Converts 5 cc (ml) of liquid into aerosol 0.3 to 5.0 microns particle size
- Complete with extra jet and replaceable plastic caps
- Break-resistant polycarbonate plastic (Lexan®) that easily disassembles for washing
- Dimensions: 2"(5.0 cm) X 2"(5.0 cm) X 7"(17.7 cm)

AVAILABLE:

2041-11K Additional Bitrex Sensitivity solution ampoules (6/box)

2041-12K Additional Bitrex Test solution ampoules (6/box)

2040-08N Additional Nebulizers (each)

