## PureFlo 3000 Powered Air Purifying Respirator





**Comfort, Quality & Trust** 

# PureFlo® Industrial Respirators Comfort, Quality & Trust

Gentex Europe is a UK manufacturer with over 100 years' experience in the production of head, face, and respiratory protection for industrial, military, and public order environments.

Our brand is synonymous with providing optimum levels of protection for personnel working in hazardous situations.

PureFlo industrial respirators are among the highest performing and most cost effective protective systems available on the market today. Proven and used throughout the world in a wide variety of heavy and light duty industries, and by numerous multinational organisations, our wide range of PureFlo industrial respirators can be configured to match your exact needs.





## Introducing the PureFlo 3000 Powered Air Purifying Respirator

The new PureFlo 3000 is an innovative powered respirator providing a unique all-in-one respiratory, head, face, eye and hearing protection solution.

The PureFlo 3000 provides integrated protection for users with an unrivalled level of comfort:

- No trailing leads, hoses, or cables provides improved safety (no "snagging").
- No belt mounted blower unit required thereby improving user comfort. Ideal for use with a range of protective workwear.
- Available for industrial, pharmaceutical and welding applications.
- No requirement for face fit testing and can be used safely with beards and/or prescription spectacles.
- Well balanced modern design.
- **High efficiency particulate filter**, gives excellent levels of respiratory protection.
- **Excellent optical vision**, for safety and comfort.
- **Comfortable fit** for prolonged use with fully adjustable head harness.
- **Robust**, quick release attachment and removal of the face and head seals.
- **Compatible** with Gentex branded ear defenders.

# No trailing leads or hosesHigh efficiency filter TH3New ADF welding lensImage: Additional control of the second control of t

## **APPROVALS**

Respiratory Protection	EN 12941:1998+A2:2008 TH3P AS/NZS1716:2012
Eye/Face Protection	EN 166:2002 1B3 EN 175:1997 EN 379:2003 + A1:2009 AS/NZS:1337.1:2010
Head Protection	EN 397:2012+A1:2012 (Hard Hat) AS/NZS1801:1997
Environmental Protection	IP54 (In Use) IPX5 (Cleaning); IEC 60509:1989
Protection Factor	Assigned Protection Factor (APF) - 40 Nominal Protection Factor (NPF) - 500


## **PRODUCT OPTIONS**

The PureFlo 3000 is available to meet the specific requirements of your application, with a range of head tops, filters and accessory options available.





**Gentex Europe** Commerce Road, Stranraer, Scotland DG9 7DX Tel: +44 (0) 1776 704421 Fax: +44 (0) 1776 706342 Email: sales@gentexcorp.eu.com Web: pureflo.gentexcorp.com







© Helmet Integrated Systems Ltd 2020, Helmet Integrated Systems Ltd is an ISO9001:2000 certified company, Gentex is a registered trademark of Gentex Corporation. Helmet Integrated Systems Ltd is a wholly owned subsidiary of Gentex Corporation. PureFlo is a registered trademark of Helmet Integrated Systems Ltd.