



SPECIFICATIONS

Product Description: **RESPIRATOR, FULL FACE**
Part Number: **9901**
Style: **SUPPLIED AIR**

GENERAL DESCRIPTION:

This comfortable full mask offers low pressure continuous flow protection with a unique over the shoulder hose design and an adjustable belt holds the hose out of the way. It's durable and easy to use and clean. **NIOSH approved.**

LENS:

- High impact polycarbonate (meets ANSI Z87.1)
- Wide field of vision with replaceable lens
- Distortion-free
- Anti-fog and anti-scratch coatings
- Available lens peel-offs (PN 9901-25)

SUSPENSION:

- Non-slip durable rubber five-point harness
- Mesh hair net minimizes pulling of hair
- Fits under hard hats
- Unique adjustable buckle system to lock in place

SEAL:

- Hypoallergenic and chemical/ozone resistant
- Durable silicone rubber maintains shape while in storage
- Comfortable even in extreme heat and cold environments
- Double sealing flange and deep chin pocket for better face to mask seal

EXHALATION VALVE:

- Large diameter contoured exhalation valve design, for minimal breathing resistance
- Easily accessible for fast replacement and cleaning
- Removable cover protects the exhalation valve form dirt, paint spray and from freezing

DOWN TUBE & BELT ASSEMBLY:

- 90° elbow allows it to be directed over the shoulder and out of the way
- Corrugated flexible and lightweight material for greater comfort and less fatigue
- OBAC quick-connect plug with wide diameter and minimal air restriction
- Low profile nylon adjustable waist belt
- Plastic clip to restrain airline hose from pulling on the face piece

NIOSH APPROVAL:

- Approval No. TC-19C-353 (Use only with Allegro approved airline hose)

